



Puck Antenna Cable Box Installation

PARTS



HyperFire Cable Box
(HFCB)



Puck Antenna

The Puck Antenna allows your HyperFire 2 Cellular camera to be used with the HyperFire Cable Box (HFCB).

1. To install the Puck Antenna you will need drill bits and a drill.
2. Drill a small pilot hole in the center of the top of the HFCB. Then drill progressively larger holes up to ½ inch (12mm).
3. Insert the shank of the antenna to verify fit.
4. Remove the adhesive backing from the bottom of the puck antenna and insert shank into the top of the HFCB.
5. Use the slotted nut to tighten the antenna shank to the top of the HFCB.
6. Remove the stock antennas from the camera and hand tighten the connector from the puck antenna to the right side of the camera (near the latch).
7. Be sure the antenna wire will not interfere with the lens or motion sensor view.

